





BOHOUMICE  
II/357

III/35726  
NOVÝ JIMRAMOV

II/357, CENTRUM

SO 101

SO 102

SO 001

SO 201

SO 201

SO 101

18

34

19

32

17

30

26

25

14

15

13

24

11

12

21

22

28

27

23

29

37

36

31

39

35

38

1248/1

st.186

st.185/3

1246/7

1247/1

st.1253

st.1254

189/2

st.206

189/4

1263/2

1263/1 (PK 205)

st.189

1273

(PK 518/1)

st.189

196/3

1202

1200/3

1200/4

st.197

196/7

1200/2

191/2

191/3

1200/1 (PK 1200/1)

1202

190

1202

191/1

1255/1 (PK 1255)

1255/1 (PK 1255)

1275

518/1 (PK 1199/1)

1263/1 (PK 1199/1)

1246/7

1199/10

1246/7

1199/12

1247/2

1199/12

1199/10

1199/12

1199/10

1199/12